

LEGEND II & POLARIS 360 HOSE INSTALLATION INSTRUCTIONS

SHORTEN HOSE:

1. THE HOSE ASSEMBLY COMES IN FIVE SECTIONS, COVERING APPROXIMATELY 30 FEET OF THE POOL, WHICH IS ENOUGH HOSE FOR MOST RESIDENTIAL POOLS. THE BACKUP VALVE IS 20 INCHES FROM THE HEAD OF THE CLEANER AND SHOULD ALWAYS REMAIN AT THIS DISTANCE. ATTACH THE FEED HOSE TO THE WALL FITTING AND ATTACH THE WALL FITTING TO THE POOL WALL. HOLD THE END OF THE HOSE AND WALK TO THE FARTHEREST CORNER OF THE POOL. DEEP END FIRST. THEN, SHALLOW END. DO NOT STRETCH THE HOSE. MEASURE THE EXCESS LENGTH BETWEEN THE FARTHEREST POINT OF THE POOL AND THE END OF THE HOSE.
2. DISCONNECT THE HOSE FROM THE WALL AND REMOVE THE PRESSURE RELIEF VALVE FROM THE HOSE. NOW, CUT THE MEASURED EXCESS FROM THAT FIRST SECTION OF HOSE. THEN, RECONNECT THE PRESSURE RELIEF VALVE TO THE HOSE AND CONNECT IT BACK TO THE POOL.

LENGTHEN HOSE:

1. FOR ADDING ADDITIONAL FEEDER HOSE FOR LARGER POOLS, YOU WILL NEED TO PURCHASE ONE ADDITIONAL HOSE SECTION, TWO FLOATS, ONE SWIVEL, AND TWO MENDER NUTS.
2. ATTACH EXTRA HOSE TO THE FIRST HOSE SECTION USING HOSE, SWIVEL, AND MENDER NUTS.
3. WHEN ASSEMBLING HOSE , SWIVELS, AND HOSE NUTS, MAKE SURE THE ROTATING END OF THE SWIVEL POINTS TOWARDS THE CLEANER HEAD AND PUT THE MENDER NUT ON THE SWIVEL FIRST, THEN PUSH THE HOSE ONTO THE SWIVEL AND TIGHTEN THE MENDER NUT CLOCKWSE UNTIL TIGHT. IF YOU ADDED ONE OR MORE LENGTHS OF HOSE, REPEAT STEP 1 TO ASSURE YOU HAVE ONLY THE CORRECT AMOUNT OF HOSE IN THE POOL, AND THEN CONNECT CLEANER HEAD TO THE HOSE AND PLACE CLEANER IN THE POOL.

POLARIS 180/ 280/ 280 & LEGEND I / PLATINUM

HOSE INSTALLATION INSTRUCTIONS

1. LAY THE FEED HOSE IN THE SUN TO RELAX AND STRAIGHTEN IT OUT.
2. MEASURE THE DEEPEST END OF THE POOL.
3. THE CLEAR HOSE IS 10 FT. LONG. IF YOUR POOL IS EIGHT FEET DEEP, THEN REMOVE THE SWIVEL CONNECTING THE CLEAR HOSE TO THE WHITE HOSE AND CUT TWO FEET OFF OF THE CLEAR HOSE. DO NOT REMOVE THE FLOAT IF IT IS IN THE WAY BUT SLIDE IT FURTHER ON TO THE CLEAR HOSE.
4. REATTACH THE CLEAR HOSE TO THE SWIVEL WITH THE ARROW INDICATING WATER FLOW POINTING AT THE POLARIS HEAD. ATTACH THE WHITE HOSE TO THE OTHER END OF THE SWIVEL. NOTE THAT THE MENDER NUT GOES ON THE SWIVEL FIRST AND THEN THE HOSE. TIGHTEN THE MENDER NUT CLOCKWISE UNTIL SNUG.
5. ATTACH THE QUICK DISCONNECT FITTING TO THE WALL AND STRECH THE HOSE TO THE FARTHEREST POINT OF THE POOL. DO NOT COUNT THE STEP AREA. IF THE HOSE IS WITHIN 6 INCHES OF THE FARTHEREST POINT OF THE POOL YOU ARE DONE WITH HOSE CUTTING.
6. IF THE HOSE IS MORE THAN 6 INCHES SHORT, ADD A 10 FOOT SECTION OF WHITE HOSE INCLUDING FLOATS.
7. YOU WILL NEED A 10 FOOT HOSE, ONE SWIVEL, AND TWO MENDER NUTS. DO NOT ADD MORE THAN ONE EXTRA SECTION OF WHITE HOSE.
8. NOW MEASURE THE AMOUNT OF HOSE THAT EXTENDS PAST THE FARTHEREST POINT OF THE POOL. THIS IS THE OVERAGE AMOUNT. DO NOT CUT THIS HOSE.
9. LAY THE HOSE ON THE DECK. GO TO THE SWIVEL BETWEEN THE TWO SECTIONS OF WHITE HOSE AND SLIDE THE FLOATS AWAY FROM THE SWIVEL. WHATEVER THE EXTRA AMOUNT IS, CUTT HALF OF THIS AMOUNT FROM EACH SECTION OF THE WHITE HOSE. REINSTALL THE SWIVEL AS IN STEP 4 ABOVE.
10. LAST, ATTACH THE CLEAR HOSE TO THE POLARIS HEAD AND PLACE THE MACHINE IN THE POOL.